

Heavy-Duty Rear Spring Kit
Yamaha G/E G14/16/19/20/22/29
Installation Instructions
Part# 6280



*Always wear appropriate
eye protection!*



ASSEMBLY INSTRUCTIONS

1. Jack the rear of the cart up and place the frame on jack stands. Place a car jack under the rear end housing of the cart.
2. Remove the rear shocks from cart. Save the nuts and bolts for reinstallation.
3. The top spring retainer must be removed from the shock. You can either cut the stock spring off the shock with a bench grinder as shown or place the shock in a vice and compress the spring with a screwdriver and pull off the retainer with a set of pliers.
4. Once the retainer is removed, slide off stock spring and dispose of it.
5. Making sure that the shock is fully extended, slide Jake's new red spring onto shock and replace stock retainer on top of the spring.
6. Push spring up tight against retainer and place the 2 piece collar (provided in the kit) in the remaining space between the spring and the bottom of shock.
7. Repeat steps 1-5 for second shock.
8. Put shocks back on cart.

NOTE: You can view an installation video of this product on our Jake's Lift Kits YouTube page.



866-405-2537

www.jakeslifitkits.com